

RÉCEPTEURS RADIO

RADIOLA		PHILIPS		RADIOLA		PHILIPS		RADIOLA		PHILIPS																																																																																																																																																																															
1932		1932		1940		1940		1950 (suite)		1950 (suite)																																																																																																																																																																															
315 A	425 A	426 A (MRP)	535 A	545 A	546 A (M)	930 A	830 A	830 A + Phono	730 A	630 A	630 A	133 U	134 U	186 A	A 43 U	A 44 U	A 446	430 A (P)	440 A (P)	511 A (MRP)	512 A (MRP)	245 A	255 A	Néant	HX 404 A	FF 504 A	FF 604 A	Néant	Néant																																																																																																																																																												
423 A	427 A	427 C	445 A et C	547 A (M)	548 A (M)	1933	830 N	834 AS	834 CS	634 A et C	630 N	630 N	133 UB	138 U	139 A	190 A	A 43 UB	A 48 U	A 49 A	A 60 A	1951	15 U	25 U	26 U	35 A et U	45 A	45 U	47 A	55 A	66 A	66 A/01	305 UB (BS)	316 A (RPT)	331 A (P)	392 V (AR)	508 V (AR)	516 A (MRP)	517 A (MRP)	BF 111 U	BF 211 U	BF 213 U	BF 311 A et U	BF 411 A	BX 400 U	BF 412 A	BF 510 A	BX 600 A	BX 610 A	LF 503 UB	HF 513 A	HF 301 A	NX 493 V	NX 601 V	FF 614 A	FF 714 A																																																																																																																																		
428 A	549 A et U	560 A et U	561 A et U	562 A et U	566 A et U	761 (M)	762 (M)	1934	834 S	638 A et U	520 A et U	521 A et U	522 A et U	526 A et U	572	572 (Luxe)	1942	142 A et U	161 A	761	1946	539 A	590 A	538 U	191 A	A 449 A	A 460 A	A 448 U	A 61	1947	73 A et U	143 A	533 U	731 A et U	751 A/X	BF 371 A et U	A 53 A	A 443 U	BF 370 A et U	BF 570 A/X	1948	74 A	77 A (MRP)	82 U	83 A	202 A (AP)	212 A (P)	217 A (AP)	218 X	223 X	230 A	310 A (P) et 311 A	570/72 V (AR)	740 A	741 A	742 A et U	BF 472 A	FF 771 A	BF 281 U	BF 381 A	HX 372 A	HX 381 A	HX 572 A	Néant	Néant	BF 373 A	HF 130 A et 131	NX 570/72 V	BF 471 A	BF 473 A	BF 471 A et U	1949	79 A (MRP)	81 U	84 A et U	93 A et U	95 A	96 A	391 V	841 A	940 A	FF 772 A	BF 181 U	BF 480 A et U	BF 393 A et U	BF 394 A	BF 690 A	NX 491 V	BF 480 A	BF 491 A	1950	11 U	20 U	30 A et U	40 A	40 U	44 A	46 A	50 A	59 A	282 U	330 A (P)	393 V (AR)	BF 101 U	BF 201 U	BF 301 A et U	BF 401 A	BX 400 U	BF 403 A	BF 406 A	BF 501 A	BF 594 A	BF 290 U	HX 303 A	NF 593 V	36 A	47 AZ	55 A FM	126 A FM	152 U	262 U	334 A (RPT)	352 A/U	395 AB (BS)	395 AB/OI (BS)	423 (P)	425 V (AR)	426 V (AR)	440 A/03 (P)	452 A	552 A	462 A	662 A	433 (P)	BF 313 A	BF 412 AZ	BX 511 A	BF 621 A FM	BF 121 U	BF 223 U	HF 434 A	BF 321 A/U	LF 422 AB	LX 422 AB	Néant	NF 524 V	NF 624 V	HF 404 A/03	BF 421 A	BF 523 A	Néant	BF 626 A	Néant	1953	263 U	353 A et U	398 AB (BS)	405 UB (BS)	429 A/FM	432 A/FM	482 A	553 A	BF 231 U	BF 331 A et U	LX 434 AB	LF 504 UB	BF 524 A	BF 634 A	BF 423 A	BF 532 A	1954	264 U	333 A	344 A (RPT)	345 A/FM (RPT)	363 A	364 A	366 A	BF 241 U	BF 332	HF 444 A	HF 539 A	BF 336 A	BF 341 A	BF 343 A
563 A et U	564 A et U	565 A	567 A et U	1935	510 A et U	525 A et U	535 A (Luxe)	535 A et U	1936	21 A et U	42 A/U	56 A/U	67 A/U	78 A	PIONNIER A et U	582 A et U	456 A/U	695 A/U	796 A/U	898 A	V 4 A et U	1937	23 A et U	43 A et U	57 A/U	68 A/U	247/248 (AR)	249/250 B (AR)	V 6 A et U	461 A et U	667 A/U	750 A/U	247/248	249/250 B	1938	10 A et U	12 A et U	17 A	18 A/U	21 B (B)	24 A/U	215 A et U	770 A et U	753 A	555 A/U	628 B	660 A/U	1939	85 A	86 A	87 U	90 A et U	94 A et U	97 A et U	103 A	112 B (B)	132 U	185 A	228 B (B)	268/69 B (AR)	A 2 N	A 446 Sensibl.	A 4 U	480 A et U	680 A et U	735 A et U	855 A	629 B	A 42 U	A 102	228 B	268/69 B																																																																																																																	

RÉCEPTEURS RADIO (Suite)

RADIOLA	PHILIPS
1954 (suite)	
383 A (RPT)	HF 546 A
383 A/OI (RPT)	HF 538 A
391 A (RPT)	HF 448 A
399 AB (BS)	LF 449 AB
435 A/FM	BX 534 A
438 A/FM	BF 633 A
463 A	BF 436 A
474 A	BF 442 A
547 A/FM (MRP)	FF 731 A
565 A/FM	BF 545 A
593 A/FM (MRP)	FF 641 A
1955-56	
125 U	BF 102 U
155 A et U	BF 151 A et U
250 A (AP)	P 550
265 U	BF 251 U
335 A (P)	HF 305 A
336 A	HF 306 A
347 A (RPT)	HF 453 A
365 A	BF 356 A
385 A	HF 568 A
392 AM/FM (RPT)	HF 548 AM/FM
394 B	LS 349 B
424 V (AR)	NF 344 V
427 V (AR)	NF 644 V
439 A (TD)	AG 2150
445 V (AR)	NF 534 V
426 V (AR)	NF 634 V
455 A	BF 451 A
467 A	BF 465 A
475 A	BF 452 A
575 A	BF 552 A
576 A (MRP)	FF 551 A
585 AM/FM	BF 555 AM/FM
586 AM/FM (MRP)	FF 556 AM/FM
361 T	L3F 16 T
569 A	B5F 96
569 A	(base 568)

RÉCEPTEURS TÉLÉVISION

RADIOLA	PHILIPS
106	601
156	651
205	502
256	652
904	402
932	390
3626	1426
3628	1428
4326	1726
4328	1728
4337	TF 1737 A
3637	TF 1437 A
3636	TF 1436 A
3646	1446
4346, AS, ST, B1, B2	1746
4334	1734
4339	1739
4347	1747
5447	2147
43 T 101	17 TX 100
4336 EN	TF 1736 EN
4346 EN	TF 1746 EN
4356	TF 1756
4357	TF 1757
4363	TF 1763
5457	TF 2157
5458	TF 2158
4361	TF 1776

LÉGENDES

- (M) - Récepteur en meuble
- (P) - Phono
- (B) - Récepteur batterie
- (MRP) - Meuble radio-phono
- (BS) - Récepteur batterie secteur
- (AP) - Phono avec ampli
- (AR) - Auto-radio
- (RPT) - Radio-phono de table